

Coverages to keep you protected from costly repairs

Pre-Owned Vehicle Coverage - Limited Powertrain Plus Plan Premium Plan Premium Plus Plan **FNGINE:** All Internal Parts • • • Balance Shafts • • • Balance Shaft Bearings & Bushings • • • Camshaft & Bearings • • • Connecting Rods & Bearings • • • Crankshaft & Main Bearings • • • Oil Pump • • • Gears & Pick-Up Screen • • • Pistons • • • Piston Rings & Wrist Pins • • • Timing Chain & Gears • • • • Timing Belt • • • Fxhaust Valves • • • Intake Valves • • • Push Rods Rocker Arms & Shafts • • • Hydraulic & Solid Lifters • • • Exhaust Manifold • • • Intake Manifold. • • • Engine Block and Cylinder Heads Valve Covers • • • Timing Cover and Oil Pan are covered only if damaged by the failure of an internal part. TRANSMISSION: • • • (Automatic or Manual Transmission) All Internal Parts Case • • • Torque Converter • • • Lock-Up Converter

- • Gears & Shafts
- • Bearings · · · Bands
- • Friction & Steel Clutch Plates
- • Steel Drums • • • Pump
- • Servo Unit Valve Body & Plate
- • Governor
- • Synohronizers
- Spacers
- • Main Drive Gear
- • Main Shaft
- • Shift Forks
- Transmission Case and Overdrive Housing are covered only if damaged by the failure of an internal part.

TRANSFER CASE:

- • All internal parts
- • Transfer Case Mounts • • • The transfer case is covered
- only if damaged by the failure of an internal part. DRIVE AXLE:
- All Internal Parts • • • Front & Rear Differential
- Orive Axle Housing
- • Ring & Pinion Gears
- • Spider Gears & Side Gears
- Bearings
- Bushings Spacers
- • Yokes
- Axle Shifts
- • Driveshaft
- • Carrier Bearings
- • I Iniversal Joints
- • Center Support Bearing • • • CV Joints
- • Drive Axel Housing is only covered if damaged by the failure of an internal part.

SEALS & GASKETS:

 Seals and Gaskets of covered components designed to prevent the loss of necessary coolants, lubricants and fluids,

FUEL SYSTEM:

- • Fuel Pump
- Injectors
- Metering Valve / Pressure Regulato
- • Turbo or Supercharger Housing and all internal parts.
- Lines & Fittings
- Fuel Gauge Sending Units
- Fuel Tank.

AIR CONDITIONING:

- Compressor
- • Compressor Clutch Accumulator
- Dryer / Receiver
- Condenser
- Evaporator Expansion Valve
- Orifice Tube
- Compressor Mounting Brackets
- . Evacuation & Recharge of Air Conditioner included when in conjunction with a covered repair.

BRAKES:

- Master Cylinder
- • Vacuum Power Assist Booster & Valve
- Hydro Booster
- Disc Brake Calipers Wheel Cylinder
- • Steel Brake Lines & Hoses.
- Pressure Differential Switch
- Parking Brake Control Pedal/ Lever
- Backing Plates
- Vacuum Booster Pump

COOLING:

- Radiator
- Water Pump
- Thermostat
- • Radiator Fan & Fan Clutch
- Electric Radiator Fan Motor
- Coolant Recovery Container
- Heater Core
- Serpentine Belt Tensioner
- Serpentine Bearing & Pulley
- Heater Blower Motor
- Blower Motor Resistor
- Blower Motor Switch
- Heater Control Valve
- Radiator Fan Shroud & Brackets.

FLECTRICAL:

- Alternator
- • Electric Horn
- • Front & Rear Wiper Motor
- Rear Defroster Switch
- Starter Motor
- Starter Motor Drive Assembly
- Starter Motor Solenoid
- Voltage Regulator
- Alternator Bracket and Pulley Power Antenna Motor
- Power Door Lock Actuators & Switches
- Power Mirror Motors & Switches
- Power Seat Motors & Switches
- Power Sun Roof
- Power Convertible Top Motor
- Power Window Motors Regulators & Switches
- Power Trunk Release Neutral Safety Switch
- Stop Lamp Brake Switch
- Washer Fluid Pump & Switch
- Electric Horn Button Emergency Warning
- All Manually Operated Switches
- Flasher Switch
- Headlamp Switch
- Headlamp Dimmer Switch
- Interior Light Switches
- Rear Window Heating Elements
- Trunk Pull Down Motor
- Turn Signal Switch
- Wiper Module & Delay Switch
- Idle Air Control Motor (IAC)
- Idle Air Control Valve (IAC)
- - Ignition Coil Ignition Distributor
 - Electronic Ignition Module
 - Stereo/Audio Equipment
 - Gauges/Driver Display
 - Cruise Control
 - Back Up Camera
 - A/C Temperature Control Module.

STEERING:


- Power Steering Pump
- Rack & Pinion
- Steering Gear Box.
- • Idler Arm & Bushings Pitman Arm
- Power Steering Pump Pulley
- Mounting Brackets & Reservoir
- • Tie Rods
- Tie Rod Ends & Sleeves
- Steering Shaft Pivot Joint.

SUSPENSION:

- Upper & Lower Ball Joints Leaf & Coil Springs (if broken)
- Spindles
- Wheel Bearings
- Upper & Lower Control Arms
- . Control Arm Bushings & Shafts
- Stabilizer Bar Links & Bushings Steering Knuckles
- Strut Bars & Bushings
- Air Suspension Compressor Spindle Supports
- Torsion Bars
- Mounts & Bushings Control Module/Processor
- Electronic & Variable Suspension Struts

CHASSIS HARDWARE:

- Hood/Door/Hatch/Trunk Latches
- Cables
- Hinges
- Supports & Springs
- Glove Box/Console Lock &
- Ignition Lock & Tumbler
- Window Regulators
- Seat Belts . Trunk & Fuel Door Release Cables or Controls
- T-Top Latches
- Manual Sunroof Latch Mechanical Seat Tracks & Springs



Additional Plan Benefits



TOWING - In the event of a breakdown covered by this contract, we will pay or reimburse you for receipted towing expenses up to seventy-five dollars (\$75) per occurrence.



reimburse you up to fifty dollars (\$50) per occurrence, for the following emergency services for your vehicle: Lock-out Assistance, Fuel Delivery Services, Battery Services, Flat Tire Assistance.

ROADSIDE ASSISTANCE - We will



RENTAL VEHICLE COVERAGE - You will receive reimbursement for up to two hundred fifty dollars (\$250) for a rental vehicle while your vehicle is being repaired.



TRIP INTERRUPTION - We will reimburse you for receipted hotel and restaurant expenses, up to one hundred dollars (\$100) per day for a maximum of three (3) days and a total benefit per occurrence of three hundred dollars (\$300).